

# smart-me

## Quick Starter Guide

### INSTALLATION

Before you can use your smart-me device, you need to connect it to your Wi-Fi Network.

1. Connect your smart-phone or tablet with your WiFi network.
2. Get the free smart-me app from the Apple App Store or the Google Play Store.
3. Start the app and create a free smart-me account.
4. Click on add device (+). The smart-me app will guide you through the installation.



Android APP

For more information visit: [smart-me.com/installation](http://smart-me.com/installation)



iOS APP

### Load profile

To show the load profile tab on the "Power" tile. The load profile shows the energy usage over a defined period of time. For more diagrams and reports visit [www.smart-me.com](http://www.smart-me.com).



### Events and Actions

To configure the events and actions go to the device details, tab on settings (top right) and choose "Event-Actions". You can define actions for some events on your smart-me device.

#### Example:

If: power is higher than 500Watt,  
Then: switch power off.

### Support

For more information please visit: [www.smart-me.com/support](http://www.smart-me.com/support)

### Security Information

- The device is intended for indoor use only.
- The device is intended for operation in a dry location that is free of dust and protected from direct sunlight.
- Frequent switching can shorten the service life of attached electrical consumers. Configure automatic switching at frequent intervals only if the connected consumers are designed for such operation. No liability will be accepted for damage on attached consumers.
- When installing or replacing the device, all connecting wires have to be disconnected from the power source.
- Touching live components (supplied with voltage) is life-threatening! Therefore, the relevant fuses are to be removed and secured in a safe location. So, nobody is able to switch the power back on undetected.
- The installation of the device must be carried out by qualified and trained professionals.
- The usual local security and work rules must be kept at all times.

## QUICK START

### Device overview


The device overview is only visible when you have more than one smart-me device logged into your account. The overview shows all of your smart-me devices. To change the grouping go to the smart-me website: [www.smart-me.com](http://www.smart-me.com)



### Device Details


The details view shows the measurement values of a smart-me device or of a group of devices. By tapping on the On / Off symbol the smart-me device (or all devices of a group) turn the power on or off.

## CONNECTION DIAGRAM



- T: Button for installation
- E1: Tariff switch (digital input)  
0V T1  
24 - 230VAC/DC T2
- S0: S0 pulse output (potential-free contact)

## DISPLAY



- T1: Tariff 1 (blinks when active) [in kwh]
- T2: Tariff 2 (blinks when active) [in kwh]
- ← → : current direction (right / left delivery)
- WLAN icon : WLAN signal strength
- No WLAN icon : no WLAN available

### Display sequence

... → Counter T1 → Counter T2 → SW Version → CRC Value → ...